

① do not remove the plastic washer until you defined your favourite configuration, mark the approx. drill holes on the wall

② what ever position you may chose, please make sure that the exact distance between the drill holes are:
A - B = 614mm
B - C = 204mm

③ for accurate drilling use first a 6mm then the 8mm drill, remove the washers from the coat hanger and put them one by one in the drill holes, now position the coat hanger and screw alternating all 3 discs, before tightening them one by one

